


## The Pre-Design Phase

### Geomorphic Based Stream Crossing Projects



Duffy Gulch, Noyo River, California

**Michael Love P.E.**  
Arcata, California  
mlove@h2odesigns.com  
707-822-2411



101



(a)

Replaced 1979 – At Grade

1998 – Culvert outlet scour  
creates large pool, resulting  
in 1-foot outlet drop



(b)

This isn't the first time we tried to get fish passage right...

*From: USFS 2008 Stream Simulation Design Manual*

102

## Primary Sources for Pre-Design Guidance

### US Forest Service, 2008

Stream Simulation: An Ecological Approach to Providing Passage for Aquatic Organisms at Road-Stream Crossings

<https://www.fs.fed.us/eng/pubs/pdf/StreamSimulation/>

### NOAA West Coast Fish Passage Guidelines

Pre-Design Guidelines for CA Fish Passage Facilities

<https://www.fisheries.noaa.gov/west-coast/habitat-conservation/west-coast-fish-passage-guidelines>



### CDFW 2009 Part XII: Fish Passage Design and Implementation Manual

<http://www.dfg.ca.gov/fish/resources/habitatmanual.asp>



### CDFW Fish Bulletins

No. 183: The Use of Log and Boulder Weirs in Stream Habitat Restoration  
No. 184: The Use of Large Wood in Stream Habitat Restoration  
No. 185: The Use of Low-Tech Process-Based Stream Habitat Restoration

### Washington Department of Fish and Wildlife, 2013


Water Crossing Design Guidelines

<http://wdfw.wa.gov/publications/01501/>

3

103

## Passage Design Process




4

104



## Surveying Channel and Floodplain Features

Arrows show rod locations for cross-section survey



Floodprone Depth Approx.  $2 \times D_{BF}$

Note: low terrace is densely vegetated with conifers, cottonwood, and shrubs.

From: USFS 2008 Stream Simulation Design Manual


105



## Making a Site Sketch of Stream Reach

Site Sketch should identify:


- Channel Bends
- Exposed Roots
- Overhanging Banks
- Bank Irregularities
- Woody Debris
- Bank Erosion
- Sediment Storage
- Sediment Inputs



106



## Longitudinal Thalweg Profile




- Extend survey well past culvert influence. Recommend Min Profile Length = 20 channel widths
- Survey captures pool depths, riffles
- Survey "forcing features" controlling grade. Note long-term stability of each forcing feature
- Survey base and top of features controlling grade. Bedrock, large colluvium, embedded wood, debris jams...


107

## Generalized Stream Classification

(from Montgomery and Buffington, 1993)



108




109

## Alignment

- Concurrent with profile design
- Important factor for debris blockage and failure
- Consider existing and future stream channel

1010




1011



1012

# Restoring Channel Geometry at Transitions




10 13

## Example of Restored Channel Geometry at Outlet



10 14

# Channel Profile Analysis



1015


# Estimating Channel Bed Structure Stability

Table 5.3—A qualitative method for determining channel-bed structure stability. (USFS Stream Simulation Manual)

Structure composition	Stability Rating	Structure Characteristics
Bedrock	High	Bedrock ledges or falls span entire stream width
Boulder-cobble steps	High	Boulder-cobble steps span entire width of stream. Rocks are tightly keyed in place, and keyed-in material extends below base of scour pool below step.
Cobble-boulder or cobble-gravel pool tail crests or riffle crests	High	Cobble-boulder or cobble-gravel pool tail crests or riffle crests span the entire width of stream. Particles are tightly packed, embedded into the channel bed, and coarser than the remainder of the channel bed.
Log	High	Wood is sound and well anchored, spanning entire stream width.
Composite log and rock	High	Wood is sound and well anchored, may or may not span entire stream width. Rock pieces are well keyed in place and bridge gaps so that composite structure controls width from bank to bank.
Boulder-cobble steps, cobble-gravel steps	Moderate	Steps do not span entire width of stream or are loosely keyed in place. Keyed-in rocks may not extend below base of scour pool below step. Alternatively, step key pieces are not in contact with each other.
Cobble-boulder or cobble-gravel pool tail crests or riffle crests	Moderate	Pool tail crests span entire width of stream, but the largest particles are similar in size to those elsewhere observed along the channel bed. Alternatively, particles are moderately packed and/or moderately embedded into the channel bed.
Log	Moderate	Wood is rotten and punky. It may span entire stream width, but anchoring is susceptible to bank scour and movement during high flood events.
Cobble-gravel steps or pool tail crests	Low	Steps do not span entire width of stream, and/or are composed of loosely packed materials. Pool tail crests are constructed of material no coarser than rest of stream bed.
Log	Low	Wood is very rotten and punky, may or may not span entire stream width, and anchoring is poor and susceptible to bank scour and movement during bankfull flood events. Indications of movement are visible where pieces are anchored into the bank.
Composite log and rock, beaver dams	Low	Wood is very rotten and punky, or structure is made of loosely packed pieces that are poorly anchored. Structure does not span entire stream width. Rock is small in size and subject to movement at bankfull flood events. Beaver dams are poorly constructed or old and inactive. Large key logs are not present.


1016

# Channel Profile Analysis



10 17


# Estimate Channel Adjustments for Life of Project



10 18

## Vertical Adjustment Potential (VAP) Profiles

Estimates the range of possible channel profiles for life of project



10 19


## Vertical Adjustment Potential (VAP)

Develop VAP with long profile and field investigations:


- ✓ Channel slopes
- ✓ Stability/mobility of channel type/material
- ✓ Channel controls and anticipated longevity [bedrock, large wood, colluvium, hard infrastructure]
- ✓ Knickpoints, evidence of active incision (downcutting) or aggradation
- ✓ Pool scour depths (low VAP)
- ✓ Bankfull and floodplain elevations (high VAP)
- ✓ Historical information (existing invert elev. and slope)

20


10 20




1021



1022



1023




1024

## Uncontrol Regrade

Wynoochee trib – 2002  
Channel regraded to bedrock

Upstream of Crossing  
Before Incision



Upstream of Crossing  
After Incision




Example from Kozmo Bates

25

10 25

## VAP Profiles for Incised Channels (no grade control – “Uncontrolled Regrade”)



10 26


## Uncontrolled Regrade – Sediment Slug

Downstream channel overwhelmed by sediment slug from headcut




27

10 27



10 28



1029

## Restoring Incised Channels and Connectivity

### Placing Wood - Profile Restoration

Neefus Gulch  
Photo: Ross Taylor







Baker Creek  
photo: Sam Flanagan, BLM

30

1030



1031



1032

## Use of Forced Profiles

(Example 2)



Jameson Creek Roughened Channel



1033


## Use of Forced Profiles

(Example 3)




34

1034



1035



1036